

FREEZER REPAIR TIPS

If the unit is not self-defrosting and the temperatures begin to rise...

Check the frost build-up on the inside of the freezer. If it is heavily frosted, manually defrost the freezer by turning it off at the thermostat. Unplug from the wall and allow 12 hours for the unit to defrost, with both doors open.

If the unit is not an automatic self-defrosting model...

Defrost the unit once a year or as often as needed. Follow the proper defrosting methods. DO NOT USE a knife, pick, hammer, chisel, screwdriver, etc. or any sharp object)

***Tech Tip** - Follow all procedures outlined under the refrigerator heading.*

***Tech Tip** - Do not pack the freezer.*

Call Topic Appliance Professionals for all of your Appliance Needs!

"Over 25 Years of Experience Servicing the Niagara Peninsula and Greater Hamilton Area"

905-929-7412