REFRIGERATOR REPAIR TIPS

If your refrigerator is not running or is not cold enough...

- 1. Turn the thermostat up to the next highest setting. If it comes on, let it run for 24 hours and check temperature to confirm it is working properly.
- Clear/remove anything blocking the air flow around the outside of the refrigerator (on top, underneath, behind, beside, in front of, etc.). Allow 3" of clearance all the way around.



- 3. If there are condenser coils on the rear of the box, make sure the box is several inches from the wall and that nothing is on top at the rear, blocking the heat from coming off the coils.
- 4. If the condenser coils are underneath the refrigerator, clean the coils with a vacuum cleaner thoroughly at least twice a year.

If the door is sticking or not closing properly...

Wipe off the face of the gasket with a wet rag and make sure the interior shelves, drawers and food are not preventing the door from closing from the inside.

Call Topic Appliance Professionals for all of your Appliance Needs!

"Over 25 Years of Experience Servicing the Niagara Peninsula and Greater Hamilton Area"

905-929-7412